

## RSCBUSB

### RS232/RS485 - USB CONVERTER CABLE



RS232/RS485 - USB converter cable, essential for the configuration and the maintenance of Dini Argeo weight indicators. The connection is fast and easy, thanks to the RJ11 quick connector on the scale side.

**The best solution  
for advanced industrial  
applications**

## MAIN FEATURES

- Length: about 1,5m
- Connectors:
  - RJ11 for the quick connection to the RS232 serial port, standard fitted on the female connector available on all Dini Argeo indicators;
  - DB9 (RSCBUSBKR)
  - USB on the PC side.
- PC minimum requirements:
  - Windows 7 or greater;
  - 2.0 USB port or greater;
  - communication drivers integrated in the Dinitools software.

**COVENTRY SCALE COMPANY**



COVENTRY SCALE COMPANY LTD

BARKERS BUTTS LANE 137 - CV61EB - COVENTRY - UNITED KINGDOM

Tel. 0044-2476-593500

Fax. 044-2476-601239

E-mail [info@coventryscale.co.uk](mailto:info@coventryscale.co.uk)

Web [www.coventryscale.co.uk](http://www.coventryscale.co.uk)